

# Mounting instruction

## AIRCELL®5

UHF-Connector, standard / item. No.: 7760



1  
Cut off cable tail right-angled.  
Move the clamping nut over the cable head. Remove 25 mm of the outer sheathing with a knife.



2  
Bend the rest of the copper braid backwards (ca. 10 mm). Slit slightly 18 mm of the copper foil and remove it. Then remove 15 mm of the dielectric.



3  
Insert the prepared cable head into the connector housing as far as it will go.



4  
Screw the cable head into the housing, so the tip of the inner conductor appears at the end of the inner pin. A safe contact between the copper braid and the housing should be achieved.



5  
Tighten the clamping nut.



6  
Solder the inner conductor and the inner pin at the tip.



7  
Screw the clamping nut until it is freely moveable on the connector housing.