









# Mounting instruction



## AIRCELL®5

N-Angle Connector, screw/solder / Art. No. 7704

 <p><b>1.</b> Cut off cable tail right-angled.</p>	 <p><b>5.</b> Slide the contact sleeve as far it goes. Scratch 5mm of the copper foil with a sharp knife and remove it. Then remove 4mm of the foamed dielectric.</p>
 <p><b>2.</b> Move the nut, clamping ring and rubber washer over the cable head.</p>	 <p><b>6.</b> Cut off the copper braid with a side cutter and move the rubber washer forward to the contact sleeve, so that the remaining braid is clamped between the rubber washer and the contact sleeve.</p>
 <p><b>3.</b> Remove 7mm of the outer sheathing with a knife.</p>	 <p><b>7.</b> Insert the so prepared cable end into the connector housing as far it goes (click) and solder the inner conductor to the inner contact.</p>
 <p><b>4.</b> Bend copper braid upwards right-angled.</p>	 <p><b>8.</b> Hand tighten the clamping nut with two 11mm open-end wrench and screw the cap firmly.</p>